

INSTRUCTIONS FOR



Vivitar

Lens/Filter Adapter

For use with Model 283
Automatic Electronic Flash Unit


The Lens/Filter Adapter for the 283 Flash, positions Vivitar Flash Filters and Vivitar Variable Angle Flash Lenses at the proper distance from the head of the unit. With the Variable Angle Lenses you can alter the angle of illumination of your 283 Flash to match the angle of coverage of your camera lens. With the Flash Filters you can do extreme close-up flash, correct the flash illumination for certain color films, and create special color effects.

Directions for use

To mount the Adapter, place the smaller end over the 283 Flash head as shown, and push it down until it snaps into place. The Adapter may be mounted with the slotted end facing either way. It is removed by simply lifting it off.

The slots in the Adapter are designed to accommodate one Lens and one Filter, or two Filters at the same time. The Lenses can only be placed in the upper slot where they

are at the precise distance from the flash head to provide optimum results. Filters should be placed in the lower slot when used in combination with a Lens, but can fit into either slot when using Filters in combination with each other.



The Lens/Filter Adapter may be left in position without Lenses or Filters for normal flash operation.

Dedicated to the late Harry Dixon and with grateful thanks
to his family for providing the original